Vauxhall warning lights chart

Red: stop when safe. Amber: get it checked soon. Lamps and colours vary by model and specification, so your car's own handbook has the final word.

	Symbol	Colour	What it means	What to do
	**Brake system**	Red	Low brake fluid or a braking-system fault	Stop when safe; do not drive on until checked
	**Engine coolant temperature**	Red	Overheating or very low coolant	Stop when safe and switch off
	**Oil pressure**	Red	Low oil pressure	Stop when safe, switch off and leave the engine off until checked
	**Airbag / SRS**	Red	Airbag or pretensioner fault; may not deploy	Stop when safe and get the SRS checked promptly
	**Charging system (battery)**	Red	Battery not charging	Stop when safe; get it checked before the battery drains
	**Electric power steering**	Red	Power-steering failure; heavy steering	Drive with care and get it checked
	**Car with spanner**	Red or amber	Engine or transmission electronics fault	Get the fault code read
	Automatic transmission	Red	Gearbox fault or fluid too hot	Avoid hard driving; get it checked
	**ABS**	Amber	ABS fault; normal brakes still work	Get it checked soon
	**ESP / traction**	Amber	Stability system off or faulty	Get it checked; with ABS lit too, suspect the ABS/ESP unit
	**Engine management**	Amber	Engine fault logged; many possible causes	Get the fault code read
	**DPF**	Amber	Filter full or blocked	Take a longer steady run; diagnosis if it stays on
	**Tyre pressure (TPMS)**	Amber	A tyre is low on pressure	Check pressures and look for a puncture
	**Glow plug / pre-heat**	Amber	Diesel pre-heating; a fault if it stays on or flashes	Normal briefly; get it checked if it persists
	**Service spanner**	Amber	Scheduled service reminder	Book a service
	Immobiliser	Amber (flashing)	Key not recognised	Try the spare key; get it checked

Full guide: sinspeed.co.uk/blog/vauxhall-warning-lights-symbols/

Print it and keep it in the car